



## INSTRUCTIONS FOR MIDI INTERFACE SEQUENTIAL CIRCUIT PRO 1

### USING THE MIDI INTERFACE

When you turn on the synthesizer for the first time, you will be in omni-on mode for receive (all channels). When you select a receive channel or other set-up, this will be stored in memory and will be remembered for when you subsequently turn on the synth - all parameters listed on the next page are stored.

If you want to put the machine back to the factory default settings at any time, switch the synth on whilst holding the red push button pressed - hold for a couple of seconds then release.

### SWITCH

When the switch is in the up position (normal) - MIDI will be disabled and all controllers will be reset to their default values so that the synth behaves completely normally & with no MIDI control. When the switch is in the down position (MIDI) - MIDI is enabled and the primary source of control is from the incoming MIDI signal.

### RED PUSH BUTTON

Two modes are available by pushing the red push button. Before you press the red button however, make sure that no notes are pressed on the synth otherwise the results may be unpredictable.

The keyboard notes required for set-up & transpose modes should be sent via MIDI from an external keyboard. (DX7/D50 etc. etc.)

#### 1) SET-UP MODE

Setting MIDI channels and assignments. Give the red push button one short press (half a second) - then release. Follow this with a note or sequence of notes as detailed on page 2. After selecting a channel you will be automatically returned to playing mode but after making assignments you will need to press the ENTER key (Top C) to return to playing mode. This is to enable you to make the multiple key presses required when re-assigning sources to destinations. (N.B. set-ups are stored in non volatile memory).

#### 2) TRANSPOSE MODE

Press and hold the red push button for four seconds - then release. Middle C will sound on the synth and continue to sound until you press a key. The note that you press will be the new middle C for MIDI IN. You can set any value up to two octaves up or down. Settings outside this range will be ignored. Note that transpose mode cannot be entered from set-up mode.

### ASSIGNING MIDI CONTROL SOURCES TO DESTINATIONS

<i>SOURCES</i>	<i>DESTINATIONS</i>	(d)=factory default
AFTERTOUCH	off / modulation (d)/ p.bend / vcf / not used	
CONTROLLER X	off / vcf (d) / not used	
CONTROLLER Y	off / vcf / not used (d)	
VELOCITY	off (d) / vcf	

C	Receive channel	1 [ Bottom C on DX 7] MIDI note number 36
Db	" "	2
D	" "	3
Eb	" "	4
E	" "	5
F	" "	6
Gb	" "	7
G	" "	8
Ab	" "	9
A	" "	10
Bb	" "	11
B	" "	12
C	" "	13
Db	" "	14
D	" "	15
Eb	" "	16
E	Omni-on mode	(default)
F	Not Used - - -	
Gb	" "	
G	" "	
Ab	" "	
A	" "	
Bb	" "	
B	" "	
C	" "	
Db	" "	
D	" "	
Eb	" "	
E	" "	
F	" "	
Gb	" "	
G	" "	
Ab	" "	
A	" "	
Bb	Notes not retrigged	
B	Notes are retrigged (default)	[also known as multiple trigger]
C	Lowest note takes precedence	
Db	Newest note takes precedence	
D	Highest note takes precedence	
Eb	Not Used	
E	Not Used	
F	p.bend & mod wheel	OFF
Gb	p.bend	ON (default)
G	mod wheel	ON (default)
Ab	controller Y	ignored (see page 3 re controller Y)
A	"	vcf
Bb	"	not used (default)
B	controller X	ignored (see page 3 re controller X)
C	"	vcf (default)
Db	"	not used
D	aftertouch	ignored
Eb	"	modulation (default)
E	"	p.bend (up only)
F	"	vcf
Gb	"	not used
G	velocity	ignored (default)
Ab	"	vcf
A	"	not used
Bb	MIDI volume	ignored
B	"	not used (default)
C	ENTER key	Press and release. [ Top C ] MIDI note no. 96

## NOTES

- 1) Controller X can be any MIDI controller. After pressing the red push button twice to enter SET-UP mode, operate the required MIDI controller before pressing the C or Db key that will assign it. If you do not operate a controller before pressing the C or Db key, then controller X will respond to MIDI controller 16 - that is General purpose controller 1 (10 hexadecimal)
- 2) Controller Y can be any MIDI controller. After pressing the red push button twice to enter SET-UP mode, operate the required MIDI controller before pressing the A or Bb key that will assign it. If you do not operate a controller before pressing the A or Bb key, then controller Y will respond to MIDI controller 17 - that is General purpose controller 2 (11 hexadecimal)
- 3) Controller X/Y will take priority over other control messages, so if controller X/Y is the mod wheel, mod wheel messages will operate whatever controller X/Y is currently assigned to, instead of operating modulation.
- 4) Receive channel and omni-on setting will return you directly to playing mode, all other keys will let you stay in SET-UP mode until you press the ENTER key (Top C)
- 5) The ENTER key (Top C) also resets all controllers to their default values - off in most cases - on for volume - centre for pitch bender.
- 6) After pressing the red push button to enter set-up mode, the first assignment that you make for any given source (after-touch for example) will cancel all other destinations currently assigned to that source - if you want to make multiple assignments, you will have to do this in the same set-up session, in other words, before you press top C. - For example - irrespective of what aftertouch was previously assigned to, pressing F (and release) will assign it to VCF only. - to make aftertouch also bend pitch, you will also have to press E ( and release) before pressing the top C which will ENTER the information and store it in n.v. memory. OTHER SET-UPS WILL REMAIN UNALTERED UNLESS SPECIFICALLY CHANGED
- 7) Control change commands recognised - (numbers in decimal)

121 reset all controllers	01 modulation wheel
123 all notes off	
124 omni mode off (always poly)	64 sustain pedal
125 omni mode on (always poly)	94 select transpose mode
126 (mono mode) = all notes off	95 select set-up mode
127 (poly mode) = all notes off	
nnn Controller X (user defined where nnn = any controller)	
nnn Controller Y (user defined where nnn = any controller)	
Controller X default = 16	Controller Y default = 17
- 8) Other commands recognised - (numbers in hexadecimal)

8nH notes off	9nH notes on & velocity
BnH control change (see above)	
DnH channel pressure (aftertouch)	EnH pitch-bend change
FEH active sensing	
- 9) The Trig/retrig switch fitted on the front panel of the PRO-ONE does not operate when the PRO-ONE is being used with MIDI. Use the software selected trig/retrig (see SET-UP MODE on pages 1 & 2) when using MIDI. (Factory default for MIDI is retrig mode on)

## MIDI CONTROL OF RED PUSH BUTTON

The red push button can be "pressed" via MIDI as MIDI switch number 95 (5Fh) for regular program mode or 94 (5Eh) for transpose mode. The selection of the push button is enough, it doesn't matter if it is being turned on or off.

In hexadecimal BX - 5F - 00 = program mode

In hexadecimal BX - 5E - 00 = transpose mode

Where X is the current MIDI channel. [N.B. whilst in program/transpose modes the MIDI is in omni on mode]

## MIDI CONNECTORS

MIDI IN should be connected to a MIDI OUT or a MIDI THRU similarly MIDI OUT should be connected only to a MIDI IN and a MIDI THRU should also be connected only to a MIDI IN.

MIDI OUT is the signal from the synthesizer (or drum machine etc.) that is to be sent to another instrument. MIDI IN is a received signal that contains MIDI information from another synth, and MIDI THRU is an exact copy of information arriving at the MIDI IN socket. This allows several instruments to be connected together.

If you want to wire your own MIDI cables the following information may be useful.

- 1) Although a 5 pin connector is used, only two connections plus an earth connection are required.
- 2) If you look at the din plug from the wiring side you will see that the pins are numbered. From left to right (or clockwise) these are 1 - 4 - 2 - 5 - 3.
- 3) The pins numbered 1 & 3 are not used.
- 4) The screen (earth) is connected to pin 2 (centre pin)
- 5) Pin 4 of one plug should be connected to pin 4 of the other
- 6) Pin 5 of one plug should be connected to pin 5 of the other
- 7) You should now have a working MIDI lead
- 8) It is preferable to label one end of the cable MIDI IN & the other end MIDI OUT, to avoid confusion.

## WARRANTY

All Kenton MIDI Kits come with a 12 month (from purchase date) back to base warranty, (i.e. customer must arrange and pay for carriage to and from Kenton Electronics).

Copyright (c) KENTON Electronics & John Price 1986-1994

**KENTON** **electronics**

**12 Tolworth Rise South, Surbiton, Surrey, KT5 9NN, UK.**

**Tel: +44 181 337 0333 Fax: +44 181 330 1060**