


KENTON

MERGE-4

4 into 2 MIDI Merge Box



Operating manual

FCC STATEMENT:

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WEEE DIRECTIVE

(applies to the European Union & other European countries with separate collection systems)



The crossed-out wheeled bin symbol affixed to this product indicates that it should not be disposed of with other household wastes at the end of its working life. To prevent possible harm to the environment or to human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable re-use of material resources.

Household users should contact either the retailer where they purchased the product, or their local government office for details of where and how they can take this item for environmentally safe recycling. Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.

For disposal in countries outside of the European Union

This symbol is only valid in the European Union (EU). If you wish to discard this product, please contact your local authorities or dealer and ask for the correct method of disposal.

EU PRODUCT SAFETY REPRESENTATIVES:

(applies to the European Union & Northern Ireland)

Manufacturer:

Kenton Electronics Ltd
Unit 3 Epsom Downs Metro Centre
Waterfield
Tadworth
KT20 5LR
United Kingdom
www.kenton.co.uk

EC Representative:

Alex4 Distribution GmbH
Lessingstr. 98, 100 – Haus 11
13158 Berlin
Germany
www.alex4.de

Description

The MERGE-4 has four MIDI Inputs and two MIDI Out ports to enable you to connect several MIDI devices to one or two MIDI inputs.

The MERGE-4 has opto-coupled MIDI Inputs and separate drive circuits for each MIDI Out socket for optimum performance. The MERGE-4 also contains active circuitry that can restore the quality of signals received at the MIDI Input that may have become degraded by losses in the MIDI cable.

The MERGE-4 is powered by a mains adaptor (supplied), so it doesn't need periodic battery changes to keep it working, enabling you to "fit and forget".

Connecting

Ensure that the power adaptor is plugged in, and the ACTIVE LED on the MERGE-4 is on. Connect the MIDI output of your keyboard(s) and/or computer to the MIDI Inputs of the MERGE-4 and connect one of the MIDI Out ports of the MERGE-4 to the MIDI input of the device you want to control.

Do not connect any of the MIDI Out ports of the MERGE-4 back to the MIDI Input of the device which is supplying data to the MIDI In port of the MERGE-4, as this may cause a MIDI loop to occur. This may cause note hangs or other undesirable effects.

The 'Active' LED blinks in response to outgoing MIDI. Be aware that if there is a large amount of MIDI data going through the Merge-4 it is possible that the LED will go out temporarily.

Merging Rules

You may find it useful to understand the following rules which the Merge-4 uses when handling certain types of MIDI data. The Merge-4 defines one of the four inputs as the *master* input for each of the following data types. One input may be the *master* for one or more data types whilst a different input may be the *master* for another data type.

MIDI Clock

When power is first applied, no input is defined as a *master* and all clock messages from all inputs will be passed until one input is defined as a *master*.

The most recent input to receive a START command (or Song Position Pointer=0 followed by CONTINUE) will become the clock *master*. That input continues to be the clock *master* until another input satisfies the above condition.

Active Sensing

The first input to receive an Active Sensing message will become the Active Sensing *master*. Active sensing messages from that input will be passed to the output, any active sensing messages received at other inputs will be ignored. An input will stay as Active Sensing *master* until no more Active Sensing messages are received at that input for a period of around 5 seconds. Then another input can become the Active Sensing *master*.

SysEx Messages

While any input is handling a SysEx message it becomes the SysEx master, and SysEx messages from all other inputs will be locked out until the message at the master input has finished. SysEx messages may be terminated either with an End Of SysEx command (F7) or with any other status command.

Firmware Version Request

You can send a SysEx message to request the version number of the firmware currently installed in the unit.

The firmware version request message is - F0 00 20 13 0E 60 F7 (hex)

The unit replies with the version number as F0 00 20 13 0E 6F xx xx xx xx F7 (hex).

Where xx is a number in ASCII and the leftmost digit is the most significant.

For example - F0 00 20 13 0E 6F 31 32 33 34 F7 (hex) = version number 1234

Specification

Power Input:	9V DC (regulated or unregulated) – never apply more than 12V (never use an unregulated supply greater than 9V as unregulated supplies typically give a higher output than shown)
Power:	60mA, 2.1mm plug (centre positive)
MIDI ports:	4 x In, 2 x Out (both deliver the same data)
Weight:	150g (excluding power supply)
Dimensions:	110 x 80 x 35 mm
Power supply:	9V regulated Multi-Region Power Supply (suitable for use in the UK, EU, US/Canada, Japan and AUS/NZ) supplied with unit.

Warranty

The MERGE-4 comes with a 12 month (from purchase date) back to base warranty, (i.e. customer must arrange and pay for carriage to and from Kenton Electronics Ltd).



Unit 3, Epsom Downs Metro Centre, Waterfield, Tadworth, KT20 5LR, UK
+44 (0)20 8544 9200 www.kenton.co.uk tech@kenton.co.uk