

INSTRUCTIONS FOR ARPEGGIO CLOCK

KORG POLYSIX

With the rear panel toggle switch in the UP position, the arpeggio clock will function as normal.

With the rear panel toggle switch in the DOWN position, the arpeggio clock will take its tempo from MIDI

If the switch is set DOWN and there is no MIDI clock present, the POLYSIX will not play.

To change the divide rate, press the push button and hold in for about six seconds, until a note sounds, (this is transpose mode) the bottom four octaves are used to set "transpose" but the top octave will set the arpeggio divide.

TOP C	= ENTER (Return to normal playing)
B	= Clock normal - no divide (full speed)
Bb	= Clock divided by 2 (half speed)
A	= Clock divided by 4 (quarter speed)
Ab	= Clock divided by 8 (eighth speed)
G	= Set triplet on (can be used with any of above)

You will need to press TOP C (Enter) after any selection.

If you want to use Triplet, you will need to set this after the divide ratio, pressing any of the divide ratios cancels Triplet.

Kenton Electronics
Brookfarm House
Station Road
South Wimbledon
London
SW19 2LP
UK

Tel +44 (0)20 8544 9200
Fax +44 (0)20 8544 9300

www.kenton.co.uk

KGP6ARPC/9608014/JKP